


REFER TO INSTALLATION INSTRUCTIONS FOR CONTROL CIRCUIT WIRING

FUSED DISCONNECT SWITCH



230/208 - 60 - 3
220/200 - 50 - 3

USE COPPER CONDUCTORS ONLY

	FACTORY WIRING	FIELD WIRING
Low Voltage	————	-----
High Voltage	————	-----

RECONNECT FROM 5-60 TO 5-30 FOR 30 MINUTE CYCLE