



REFER TO INSTALLATION INSTRUCTIONS FOR CONTROL CIRCUIT WIRING

FUSED DISCONNECT SWITCH



240 / 220 - 50 - 1

EQUIPMENT GROUND



USE COPPER CONDUCTORS ONLY

	FACTORY WIRING	FIELD WIRING
Low Voltage	————	- - - -
High Voltage	————	- - - -

RECONNECT FROM 5-60 TO 5-30 FOR 30 MINUTE CYCLE