




REFER TO INSTALLATION INSTRUCTIONS
FOR CONTROL CIRCUIT WIRING.



FUSIBLE
DISCONNECT
SWITCH



USE COPPER
CONDUCTORS ONLY

	FACTORY WIRING	FIELD WIRING
Low Voltage	—————	- - - - -
High Voltage	—————	- - - - -

240/220 - 50 - 1