



THIS HEATER PACKAGE CONSISTS OF THE FOLLOWING:  
 (1) BASIC HEATER PACKAGE  
 (1) TERMINAL BLOCK (CAT. NO. ERB OR 11993)  
 (1) LISTED GROUND TERMINAL 6-12 AL, 6-14 CU

REFER TO THE HEAT PACKAGE INSTRUCTIONS FOR PROPER INSTALLATION. SECOND HEATER CONTACTOR OPERATES ONLY DURING EMERGENCY HEAT OR COMPRESSOR CUTOFF.

USE COPPER OR ALUMINUM WIRE \* 50HZ APPLICATION NOT U.L. LISTED

	FACTORY WIRING	FIELD WIRING
Low Voltage	— — — — —	- - - - -
High Voltage	— — — — —	- - - - -

240/208-60-1  
 240/220-50-1 \*