



- ⚠ THIS HEATER PACKAGE CONSISTS OF THE FOLLOWING:
 - (1) BASIC HEATER PACKAGE
 - (1) TERMINAL BLOCK (CAT. NO. ERB OR 11993)
 - (1) LISTED GROUND TERMINAL 6-12 AL, 6-14 CU
- ⚠ REFER TO THE HEAT PACKAGE INSTRUCTIONS FOR PROPER INSTALLATION. SECOND HEATER CONTACTOR OPERATES ONLY DURING EMERGENCY HEAT OR COMPRESSOR CUTOFF.

USE COPPER OR ALUMINUM WIRE * 50HZ APPLICATION NOT U.L. LISTED

	FACTORY WIRING	FIELD WIRING
Low Voltage	_____	-----
High Voltage	—————	-----

240/208-60-3
240/220-50-3 *