



- ⚠ THIS HEATER PACKAGE CONSISTS OF THE FOLLOWING:
 - (1) BASIC HEATER PACKAGE
 - (1) TERMINAL BLOCK (CAT. NO. ERB OR 11993)
 - (1) LISTED GROUND TERMINAL 6-12 AL, 6-14 CU
- ⚠ REFER TO THE HEAT PACKAGE INSTRUCTIONS FOR PROPER INSTALLATION. SECOND HEATER CONTACTOR OPERATES ONLY DURING EMERGENCY HEAT OR COMPRESSOR CUTOFF.

USE COPPER OR ALUMINUM WIRE

	FACTORY WIRING	FIELD WIRING
Low Voltage	—	- - - -
High Voltage	—	- - - -