



LOW VOLTAGE SENSOR CONNECTIONS



NOTE: USE CLASS ONE WIRING FOR CONNECTION TO THE LOW VOLTAGE TERMINAL BLOCK

4084-135 B

LOW VOLTAGE SENSOR CONNECTIONS



NOTE: USE CLASS ONE WIRING FOR CONNECTION TO THE LOW VOLTAGE TERMINAL BLOCK

4084-135 B