


4084-146


LOW VOLTAGE SENSOR CONNECTIONS



NOTE: USE CLASS ONE WIRING FOR CONNECTION TO THE LOW VOLTAGE TERMINAL BLOCK

4084-146

LOW VOLTAGE SENSOR CONNECTIONS



NOTE: USE CLASS ONE WIRING FOR CONNECTION TO THE LOW VOLTAGE TERMINAL BLOCK