



NOTE:  
 BARD 8403-066  
 CONTROLLER  
 MUST BE USED  
 WITH THESE UNITS.  
 A THERMOSTAT WILL  
 NOT WORK.

Wires Connect if Option Not Used	99 Wire Identification numbers for Bard use only.		
	Factory	Field	Optional
High Voltage	-----	-----	-----
Low Voltage	-----	-----	-----

**WARNING**  
 USE COPPER CONDUCTORS  
 ONLY SUITABLE FOR AT LEAST  
 75° C.

**DANGER**  
 ELECTRICAL SHOCK HAZARD  
 DISCONNECT POWER BEFORE  
 SERVICING.

**Bard**  
 SINCE 1914

Bard Mfg. Co.  
 Bryan, Ohio

4095-354 D