



NOTE:
 BARD 8403-066 CONTROLLER
 MUST BE USED WITH THESE
 UNITS. A THERMOSTAT WILL NOT WORK.

<p>A</p> <p>Wires Connect if Option Not Used</p>	<p>99 Wire Identification numbers for Bard use only.</p>		
	Factory	Field	Optional
High Voltage	---	---	---
Low Voltage	---	---	---

WARNING
 USE COPPER CONDUCTORS ONLY SUITABLE FOR AT LEAST 75° C.

DANGER
 ELECTRICAL SHOCK HAZARD
 DISCONNECT POWER BEFORE SERVICING.