



NOTE:  
BARD 8403-066 CONTROLLER  
MUST BE USED WITH THESE  
UNITS. A THERMOSTAT WILL NOT WORK.

 Wires Connect if Option Not Used	Factory	Field	Optional
	High Voltage	-----	-----
Low Voltage	-----	-----	-----

Wire Identification numbers for Bard use only.		
Factory	Field	Optional
High Voltage	-----	-----
Low Voltage	-----	-----

**WARNING**  
USE COPPER CONDUCTORS  
ONLY SUITABLE FOR AT LEAST  
75° C.

**DANGER**  
\*ELECTRICAL SHOCK HAZARD  
\*DISCONNECT POWER BEFORE  
SERVICING.

4095-375 D