"X" Thermostat Options



4102-072 B

1 *Factory Installed Jumper.*

2 *Remove for 2 stage electronic heat on 15 KW models.*

3 *Must be re-configured from default of Heat Pump to Heat/Cool.*

4 *Must be configured for Heat/Cool and No Economizer for proper operation and for Humidity Control output "D/Yo" to be active.*

5 *Field Installed Jumper*