

REPLACEMENT PARTS MANUAL

PACKAGED AIR CONDITIONER AND HEAT PUMP HEATER PACKAGES MODEL EH3PA

Manual 2110-301

Revision --

Date 8-11-89

Supersedes

* GENERAL NOTES *

*Revised and/or additional pages may be issued from time to time.
*A complete and current manual consists of pages dated as shown in the following index.


** INDEX **

<u>Page Description</u>	<u>Page</u>	<u>Date</u>	<u>Supersedes</u>
Functional Components--A series--Layout	1	8-11-89	
" " --Usage List	2	8-11-89	
Functional Components--B and C series--Layout	3	8-11-89	
" " --Usage List	4	8-11-89	

*** IMPORTANT ***

Contact the installing and/or local Bard distributor for all parts requirements. Make sure you have the complete model and serial number available from the unit rating plate.

FUNCTIONAL COMPONENTS




Date: 8-11-89
Supersedes:

FUNCTIONAL COMPONENTS

Dwg. No.	Part No.	Description	B H 3 P A A 0 5	B H 3 P A A 0 8	B H 3 P A A 0 1 0	B H 3 P A A 1 5
1	117-073	Heater Box Assembly	X	X	X	X
2	8604-089	Heat Strip 5KW 240V	X			
2	8604-090	Heat Strip 8KW 240V		X		
2	8604-091	Heat Strip 10KW 240V			X	
2	8604-047	Heat Strip 15KW 240V				X
3	136-091	Fill Plate	X	X	X	
4	8402-026	Thermal Cutoff	1	2	2	3
5	8402-012	Limit Control	X	X	X	X
6	8401-006	Contactoer	X	X	X	2
7	8201-008	Blower Relay	X	X	X	X
8	3000-904	Wire Assenbly	X	X	X	
8	3000-903	Wire Assenbly				X
9	8614-017	Fuse Block				X
10	8607-013	Terminal Block	X	X	X	
	132-033	Control Panel Cover (not shown)	X	X	X	X
THE FOLLOWING PARTS CONTAINED IN THE PLASTIC BAG						
	8607-013	Terminal Block	X	X	X	X
	8611-006	Ground Terminal	X	X	X	X
	4067-110	Wiring Diagram	X			
	4067-120	Wiring Diagram		X	X	
	4067-130	Wiring Diagram				X

Date: 8-11-89
Supersedes:

FUNCTIONAL COMPONENTS



Date: 8-11-89
Supersedes:

FUNCTIONAL COMPONENTS

Dwg. No.	Part No.	Description	E H 3 P A B O 9	E H 3 P A B 1 2	E H 3 P A B 1 5	E H 3 P A C 0 9	E H 3 P A C 1 2	E H 3 P A C 1 5
1	117-073	Heater Box Assembly	X	X	X	X	X	X
2	8604-048	Heat Strip 9KW 240V	X					
2	8604-046	Heat Strip 12KW 240V		X				
2	8604-047	Heat Strip 15KW 240V			X			
2	8604-072	Heat Strip 9KW 480V				X		
2	8604-051	Heat Strip 12KW 480V					X	
2	8604-052	Heat Strip 15KW 480V						X
3	136-091	Fill Plate	X			X		
4	8402-026	Thermal Cutoff	2	3	3	2	3	3
5	8402-012	Limit Control	X	X	X	X	X	X
6	8401-006	Contactora	X	X	X			
6	8401-002	Contactora				X	X	X
7	8401-006	Contactora			X			
8	3000-904	Wire Assembly	X			X	X	X
8	3000-903	Wire Assembly		X	X			
9	8607-014	Terminal Block	X	X	X	X	X	X
10	8607-015	Phenolic Insulator				X	X	X
11	8201-008	Blower Relay	X	X	X			
11	8201-032	Blower Relay				X	X	X
	132-033	Control Panel Cover (not shown)	X	X	X	X	X	X
THE FOLLOWING PARTS CONTAINED IN THE PLASTIC BAG								
	8607-014	Terminal Block	X	X	X	X	X	X
	8611-006	Ground Terminal	X	X	X	X	X	X
	8607-015	Phenolic Insulator				X	X	X
	4067-210	Wiring Diagram	X					
	4067-220	Wiring Diagram		X	X			
	4067-310	Wiring Diagram				X		
	4067-320	Wiring Diagram					X	X

Date: 8-11-89
Supersedes:

