## Replacement Parts Manual

# ADJUSTABLE FRESH AIR DAMPER

**MODELS: AFAD-3** 

AFAD-5

#### **General Notes**

- Revised and/or additional pages may be issued from time to time.
- A complete and current manual consists of pages shown in the following contents section.


#### Contents

Usage List ...... 3


### **Important**

Contact the installing and/or local Bard distributor for all parts requirements. Make sure you have the complete model and serial number available from the unit rating plates.

Manual: 2110-674 File: Tab 19 Date: 08-28-98



This Exploded View referenced in Table on Page 3



This Exploded View referenced in Table on Page 3

## CABINET and FUNCTIONAL COMPONENTS - AFAD-3 and AFAD-5

Drawing			AFAD-3	AFAD-5
No.	Part No.	Description	AF	AF.
1	127-215	Base	<u> </u>	X
1	127-212	Base	X	!
2	100X263	Right End		X
2	100X245	Right End	x	
3	8602-038	Damper Blade Pin	X	X
4	100Y263	Left End		X
4	100Y245	Left End	l x	<u> </u>
5	8602-039	Bronze Bushing	2	2
6	137-218	Rear Fill		Х
6	137-178	Rear Fill	X	
7	137-217	Return Air Fill		X
7	137-179	Return Air Fill	×	
8	139-067	Damper Blade		X
. 8	139-053	Damper Blade	x	
9	7003-035	Mist Eliminator		Х
9	7003-033	Mist Eliminator	×	
10	131-095	Filter Stop	2	2
11	105-1044	Adjustment Angles	2	2

This Table references Exploded Views on Pages 1 and 2