



Wall-Mount™ Air Conditioners

Table Of Contents

Document	Description
CT - Wall-Mount™ Air Conditioner Models	
CT	Series Cabinet Air Conditioner Units CT Series Ventilation Options
W**A - Wall-Mount™ Air Conditioner Models	
W**A	Series Standard Units ~ R-410A Refrigerant
W**A	Series Dehumidification Units ~ R-410A Refrigerant W**A Series Electric Heat Options-Right Hand Ventilation Options
W*RV	Series Variable Capacity ECU ~ R-410A Refrigerant
W*L - Wall-Mount™ Air Conditioner Models	
W**L	Series Left-Hand Units ~ R-410A Refrigerant W**L Series Electric Heat Options-Left Hand Ventilation Options
W*LV	Series Variable Capacity ECU ~ R-410A Refrigerant
WA - Wall-Mount™ Air Conditioner Models	
WA*S	Series 'Step Capacity' Units ~ R-410A Refrigerant WA 'Step Capacity Electric Heat Options-Right Hand Ventilation Options
WL*S	Series 'Step Capacity' Units ~ R-410A Refrigerant WL 'Step Capacity Electric Heat Options-Left Hand Ventilation Options
WA	Series Standard Units ~ R-22 Refrigerant Ventilation Options
WA	Series Hot-Gas By Pass Units ~ R-22 Refrigerant
WA	Series Right Hand Dehumidification – D053 Electric Reheat Units ~ R-22 Refrigerant
WA	Series Dehumidification – Hot Gas Reheat Units ~ R-22 WA Series Electric Heat Options
WC - Wall-Mount™ Air Conditioner Models	
WC	Series Chilled Water Units
WE - Wall-Mount™ Air Conditioner Models	
WE	Series Standard Units ~ R-407C Refrigerant

[WE Series Electric Heat Options](#)
[Wall-Mount Ventilation Options](#)

WL - Wall-Mount™ Air Conditioner Models

WL	Series Left Hand Wall-Mount™ Air Conditioner Units ~ R-22
WL	Series Hot-Gas By Pass Units ~ R-22 Refrigerant
WL	Series Left Hand Dehumidification – D053 Electric Reheat Units ~ R-22 Refrigerant WL Electric Heat Options Wall-Mount Ventilation Options
MAC	Series Wall-Mount™ Air Conditioner Units ~ R-22 Refrigerant

Wall-Mount Heater Packages By Series Number

[Heater Parts Manual Link](#)