



Climate Control Solutions
Bard Manufacturing Company, Inc.
Bryan, Ohio 43506

RISER PLATFORM with TRIM KIT INSTALLATION INSTRUCTIONS

IRP3 (3-INCH RISER)
IRP6 (6-INCH RISER)

UNIT PREPARATION

1. Remove packaging material.
2. Remove shipping brackets and lift unit off from wooden skid per the I-TEC Installation Instructions.
3. Remove cabinet doors and sides.

RISER PLATFORM ASSEMBLY & INSTALLATION


1. Place riser base on floor with rails facing upward. If there is adequate clearance to work on the sides of the unit, position the riser platform in its final installation location. If not, place it in a convenient place to work and then move into position later.





2. Lift the I-TEC and place it on the riser base centering the locating extrusions on top of each other.




3. Install base connection plates on the front of the unit using screws supplied with the kit.



4. If a forklift or other lifting device is required to move the unit into the installed position, then do so now before proceeding to Step 5.
5. Install side trim. The side trim pieces are attached using a sheet metal screw on the front of the base and a plastic canoe clip in the rear. For ease of assembly, install the canoe clips first and then the screws.



6. Install front trim. The front trim is attached using two (2) sheet metal screws and two (2) canoe clips. The sheet metal screws attach the top of the trim to the I-TEC unit and the canoe clips attach the bottom of the trim to the riser base. For ease of assembly, install the canoe clips first and then the screws.



7. Install cabinet sides and doors. Installation is now complete.

