

USE COPPER OR ALUMINUM WIRE


- ⚠️ Capacitor provides off-cycle crankcase heat.
- ⚠️ See alternate thermostat sheet. Set heat anticipator at .40A.
- ⚠️ For 208V operation move this wire to 208V transformer tap.

Fused Disconnect Switch

230/208-60-1

MODELS
20WA1 & 24WA2
w/8 or 10 KW

Factory Wiring ———
Field Wiring - - - - -



5-Minute
Anti-Cycle
Relay

USE COPPER OR
ALUMINUM WIRE

- 1 Capacitor provides off-cycle crankcase heat.
- 2 See alternate thermostat sheet. Set heat anticipator at .40A.

230/208-60-1

**NEW DIAGRAM
ADD TO FILE
DATE 10-28-82**

MODELS
20WA1 & 24WA2
w/8 or 10 KW

Factory Wiring _____
Field Wiring - - - - -