

X G R Y1 W1 W2 W3 E L T872N1036/Q672F1299
OR
T874N1024/Q674F1261

X2 X1 G R Y1 B W2 W3 E L T872R1164/Q672L1185
OR
T874R1129/Q674L1181

C G R Y1 B W1 W2 W3 E L DH O1

24V Terminal Block

Compressor

Internal Overload

Immersion Crankcase Heater

COMPRESSOR CONTACTOR

208V 24V

High Pressure Switch

Capacitor 15/370

Outdoor Motor

Outdoor Motor Relay

Defrost Relay

Defrost Thermostat

Defrost Timer

BLOWER RELAY

10/370V Capacitor

Indoor Motor

Heating Blower Relay

Limit

230V Terminal Block

230

Transformer

460

Heater Contactor

Thermal Cutoff

Electric Heater

Terminal Block

LL3 LL2 LL1

Equip. Ground

USE COPPER OR ALUMINUM WIRE


⚠ If there is an X1 and X2 terminal on Q674L1181, Jumper them together and connect from C to either one.

⚠ For 208V operation move this wire to 208V transformer tap.

MODELS
42WH-3, 48WH5-3
Heat Pump
9, 12, 15 KW

FACTORY WIRING	FIELD WIRING
Low Voltage ———	—————
High Voltage ———	—————

Fused Disconnect Switch



460-60-3

4014-320P